

Delta/ Brizo Rough-in Cheat Sheet

Function	Delta	Brizo
Multichoice Universal	R10000	R60000
Diverter	R11000	R60700
Integrated	R22000	R75000
Roman Tub Filler (Less hand shower)	R2707	R62707
Roman Tub filler (With hand shower)	R4707	R64707
Wall Mounted Tub filler	R3500-WL ✘	R70400
Floor Mounted Tub Filler *Might need conversion hardware*	R4700-FL ✘	R70100
2 Handle Wall Mounted Lav	R3500-WL	R65800
1 Handle Wall Mounted Lav	R3510-WL ✘	R65700
2-hole 1 Handle Wall Mounted Lav	R3510-WL ✘	R85800
Hydrachoice Body Spray	R50200	R84100

		Delta Trim	Brizo Trim
		<i>Single Post Free-standing tub filler</i>	<i>Single Post Free-standing tub filler</i>
Delta Rough-in	R4700-FL	No Hardware Kit Necessary	Need hardware conversion kit RP74819
	R4700-FLWS	No Hardware Kit Necessary	No Hardware Kit Necessary
Brizo Rough-in	R70100	Need hardware conversion kit RP75217	No Hardware Kit Necessary
	R70100-WS	Need hardware conversion kit RP75217	No Hardware Kit Necessary

Are the R3500-WL and the R65800 the same rough-in?

Yes, the roughs are the same but where the difference comes into play is you can't use the extension kit (RP91933) on the Brizo (R65800)

Are the R3500-WL and the R70400 the same rough-in?

No, they are not the same rough-in.

Can an adapter be used on the R3500-WL and the R70400 to use a non-diverting tub spout?

Yes, there is a .biz positing on this.

<https://www.deltafaucet.biz/news/2021/Brizo+and+Delta+Wall+Mount+Tub+Filler+Adapters.html>

